

























Instruction Manual

STARRY 4  USER MANUAL	 21+																		
SHARE THE VIEW: Take a video using the product with #XMAXVAPORIZER and we will share it with our global family.  @XMAXVAPORIZER.CN  @XMAX.VAPORIZER	CAUTION 1. Please do not put this product away or leave it for extended periods of time with low charge because if the battery falls below 2% then it will no longer accept a charge. 2. Charge the battery with a good quality & dedicated charger, never more than 5V/1A. Otherwise, it will cause damage to battery, serious personal injury, fire.  3. Do NOT use damaged batteries in all our vaporizers. 4. Please use our original batteries or high quality batteries from authentic brands instead of clones. 5. Always use battery suitable for your device. Never carry it loose in your pocket with other metal objects. 1																		
  Do not over load the device chamber with desired materials, for devices with variable temperature settings please find the best setting that is comfortable and safe for your enjoyment. DISCLAIMER Thank you for purchasing the XMAX STARRY 4. To ensure the best experience, please read and understand the user manual fully before your first use of the XMAX STARRY 4. We strongly recommend you keep these user manual for future reference. We hope you enjoy the excellent quality and performance of your new XMAX STARRY 4. User must be of legal age within any given jurisdiction to purchase or use the XMAX STARRY 4, use this product 2	in moderation. This product should not be used by a child, while driving or operating heavy machinery, minors, or women who are pregnant and/or breast feeding and those with life threatening illnesses without first consulting a doctor. California Prop 65 WARNING: This product contains chemicals known by the state of California to cause cancer, birth defects or other reproductive toxicity. The vaporized aerosol of chemicals are known to cause respiratory or other diseases and in some cases are irreversible. If needed contact your local poison control center, USA: AAPCC 1-800-222-1222. 3																		
Note that the XMAX STARRY 4 is not a medical device and is not intended to administer medicinal or illegal substances of any kind, diagnose, cure, treat or prevent any diseases or other conditions. Any illegal use of this device could subject the user to severe fines, penalties and/or imprisonment under the law of their (and/or other) jurisdictions. THIS PRODUCT DOES NOT CONTAIN ANY BOTANICAL MATERIAL. 4	XMAX STARRY 4 OVERVIEW  5																		
XMAX STARRY 4 CONTENTS  SPECIFICATIONS <table><tr><td>Battery Capacity</td><td>18650 3.7V 2550mAh</td></tr><tr><td>Charger/ Output Voltage</td><td>5.0V/ 1A</td></tr><tr><td>Charging</td><td>USB-C charging</td></tr><tr><td>On/Off</td><td>Click the Power button 3 times</td></tr><tr><td>Safety Power Duration</td><td>4 minutes/ 6minutes/ 10minutes optional</td></tr><tr><td>Heating Chamber</td><td>Ceramic with embedded heating element</td></tr><tr><td>Screen</td><td>OLED</td></tr><tr><td>Temperature Range</td><td>100°C~240°C (212°F~464°F)</td></tr><tr><td>Size</td><td>115.9*37.5*24mm (4.56*1.48*0.94inch)</td></tr></table> 6	Battery Capacity	18650 3.7V 2550mAh	Charger/ Output Voltage	5.0V/ 1A	Charging	USB-C charging	On/Off	Click the Power button 3 times	Safety Power Duration	4 minutes/ 6minutes/ 10minutes optional	Heating Chamber	Ceramic with embedded heating element	Screen	OLED	Temperature Range	100°C~240°C (212°F~464°F)	Size	115.9*37.5*24mm (4.56*1.48*0.94inch)	OPERATION GUIDE 1. CHARGE  Fully charge device at least 6 hours before first use. Please use the provided USB-C cable to charge your device. A charging icon will appear on the display to indicate that it is being charged. When the device is fully charged, the charging icon will always be on.  Charge the battery with good quality and dedicated charger. Please ensure the output of wall charge is no more than 5V/1A, or it will damage the device. 7
Battery Capacity	18650 3.7V 2550mAh																		
Charger/ Output Voltage	5.0V/ 1A																		
Charging	USB-C charging																		
On/Off	Click the Power button 3 times																		
Safety Power Duration	4 minutes/ 6minutes/ 10minutes optional																		
Heating Chamber	Ceramic with embedded heating element																		
Screen	OLED																		
Temperature Range	100°C~240°C (212°F~464°F)																		
Size	115.9*37.5*24mm (4.56*1.48*0.94inch)																		
2. LOAD How to use the oven: Remove the magnetic mouthpiece lid and choose which botanical substance is best for you. Due to the oven's delicate technology, please be gentle when packing the oven and/or inserting the oven cup and / or cleaning.  Botanical flower: Loosely pack the ground substance in the oven chamber, do not let the substance beyond the top of the oven chamber. Dosing capsule: Open the cap of the dosing capsule, load the desire substance into the dosing capsule, then insert the dosing capsule into the oven chamber.  Do not over load the cup chamber. It is recommended to fill half of the cup's capacity. 8	3. POWER ON/OFF  Click power button 3 times, the XMAX STARRY 4 will power up and begin to heat up under the default setting or your last temperature setting. Click the power button 3 times to turn off and the XMAX STARRY 4 will vibrate to indicate shut down. 4. ENJOY XMAX STARRY 4 While heating, The " " will keep blinking during the heat-up stage, the " " will become solid and device vibration indicates readiness and the timer countdown starts. Inhale through the mouthpiece and enjoy. This device will automatically begin vaping.  9																		
5. TEMPERATURE SETTINGS  Press or hold the up button to increase temperature, press or hold the down button to decrease temperature. Click to change by degree, hold to change quickly. 6. TIMER SWITCHOVER  XMAX STARRY 4 has 3 timers, 4 minutes, 6 minutes and 10 minutes. To switchover the 4 minutes, 6 minutes and 10 minutes, just hold the power button and up button at the same time for 2 seconds. 10	7. FAHRENHEIT AND CELSIUS SWITCHOVER To switchover to fahrenheit, just hold the power button and down button at the same time for 2 seconds.  8. ADJUST AIRFLOW Push the air adjust button up and down to adjust the smoothness of the airflow.  11																		
9. SCREEN FLIP Hold the up button and down button at the same time for 2 seconds.  10. OLED DISPLAY  Battery level Target temperature Current temperature 464°F 05:59 Session timer 12	11. CLEANING & MAINTENANCE To keep the XMAX STARRY 4 working optimally and maintaining the purest taste, we recommend that all parts which come in contact with material or vapor be cleaned regularly. All removable parts can be disassembled for optimal cleaning. Mouthpiece & filter Use a cotton swab and wipe the inner part of the mouthpiece then wipe again with a damp paper towel. Prepare a glass container filled with isopropyl alcohol. Remove the filler from magnet cap, and place it in the isopropyl alcohol.  13																		
Ceramic oven cleaning: use brush to sweep inside and cotton swab dipped in isopropyl alcohol.  * Tip: Perform a burnoff cycle at max temp for 2 minutes after cleaning. After using the XMAX STARRY 4 or charging, please allow the device to cool down before storage. It should be stored in a clean, dry place protected against the effects of weather and out of the reach of children and pets. If you have any concerns or if there is any problem, please switch off the XMAX STARRY 4 and/or remove it from the charger immediately. Do not try to remedy any defect yourself. Contact our customer service directly at support@topgreencig.com. 14	NOTE:  DO NOT TOUCH THE HEATING ELEMENT IMMEDIATELY AFTER USE. DO NOT CLEAN THE WHOLE DEVICE WITH WATER OR SUBMERGE. DO NOT INJECT ANY LIQUID OR OIL INTO THE STAINLESS STEEL OVEN. MAKE SURE DEACTIVATE THE DEVICE BY LOCKING. MAKE SURE IT HAS NOT BEEN USED FOR AT LEAST 30 MINUTES AND IS COMPLETELY COOLED OFF. WARNING: HOT COMPONENTS 15																		
SAFETY Prior to your first use, please read and fully understand the user manual including the safety information. We recommend that these user manual be kept for future reference. Failure to follow warnings may result in a safety hazard including electric shock, fire, property damage, bodily injury or death. AGE Must be of legal age in your jurisdiction to purchase or use the XMAX STARRY 4. For adult use only. USE Never use the product before reviewing the manual in its entirety. If any section or topic is unclear prior to use, please contact customer service for clarification. This product should not be used by children, women who are pregnant or breast feeding, or those with life threatening illnesses without first consulting a doctor. It is 16	recommended that all users consult a doctor prior to use with your chosen herb or concentrate. Note that the XMAX STARRY 4 is not a medical device and is not intended to diagnose, cure, treat, or prevent any diseases or other medical conditions. XMAX STARRY 4 is not intended to administer medicinal or illegal substances of any kind. Any illegal use of this device could subject the user to severe fines, penalties, and/or imprisonment under the laws of your local jurisdiction. DAMAGE Immediately discontinue use of the product if the vaporizer unit is damaged in any way including but not limited to: dents, overheating, unusually restrictive airflow, and/or electrical malfunctions. Do not attempt to repair product by disassembly of non-replaceable parts except mouthpiece, filter, packing tool, and removable battery. Please contact customer service for help with any damaged unit. 17																		
All batteries may explode or burst into flame if used improperly or mistreated. Do not disassemble, puncture, tamper, cut, crush, short-circuit, incinerate or expose to water, fire or high temperature above 60°C or 140°F. It is your responsibility to understand the dangers as well as the proper procedures for handling all batteries. Do not dispose of in trash containers nor litter the environment. Please recycle or dispose according to local safety regulations law. (Suggested to cover terminals with proper insulating tape before disposal.) WARNING THIS PRODUCT IS NOT INTENDED FOR NICOTINE. PRODUCT IS DESIGNED FOR LEGAL BOTANICALS AND CONCENTRATE USE ONLY. PRODUCT DOES NOT CONTAIN ANY BOTANICALS OR CONCENTRATE MATERIALS. KEEP DEVICE AWAY FROM CHILDREN AND PETS. 18	LIMITED WARRANTY The product's warranty period is 12 months from the date of purchase (with receipt) or 12 months from the date of production (without receipt) to prevent defects in manufacturing, workmanship, and materials. This device is designed for the use of legal herb and concentrates only. Any use of the XMAX STARRY 4 with illegal substances will void the warranty. This warranty covers only the electronic base. This warranty does not warrant mouthpiece, battery cell, scraping tool and/or other detachable parts. The warranty does not apply to damage caused by accident, abuse, misuse, natural disaster, user error, or use outside the intended use described in the manual. Use outside the intended use as described in this manual also includes any tampering with device in any way, including but not limited to modification to alter functionality or modification to alter appearance. 19																		
The warranty also does not apply to cosmetic damage including but not limited to dents, scratches/chips to finish, and/or broken plastic parts. Normal product wear and tear is not covered under warranty. Normal performance degradation of batteries is also not covered by the warranty. To make a warranty claim, please contact customer support at support@topgreencig.com. The original bill of sale, authenticity code, pictures or videos, and any serial numbers are required to redeem the warranty. At the manufacturer's discretion, warranty service will be provided by repair of the product or exchange of the product and/or part with a new or functionally equivalent product/part. 20	CUSTOMER SUPPORT For any question or concerns with the product, its use or defects, please contact customer support at support@topgreencig.com. We will do our best to provide a response within two (2) business days after receipt of written notice. 21																		

Manual de instrucciones

STARRY 4  USER MANUAL	 21+
SHARE THE VIEW: Take a video using the product with #XMAXVAPORIZER and we will share it with our global family.  @XMAXVAPORIZER.CN  @XMAX.VAPORIZER	PRECAUCIÓN 1. Por favor no guarde este producto ni lo deje por períodos de tiempo prolongados con poca carga ya que si la batería cae por debajo del 2% entonces dejará de aceptar carga. 2. Cargue la batería con un cargador de buena calidad y dedicado, nunca de más de 5V/1A. De lo contrario, podría causar daños a la batería, lesiones personales graves e incendios.  3. NO utilice baterías dañadas en ninguno de nuestros vaporizadores. 4. Por favor utilice baterías originales o de alta calidad y de marcas auténticas en lugar de clones. 5. Utilice siempre baterías aptas para su dispositivo. Nunca lo lleve suelto en su bolsillo con otros objetos metálicos. 1
  No sobrecargue la cámara del dispositivo con los materiales deseados, en el caso de los dispositivos con ajustes de temperatura variables, por favor encuentre la mejor configuración que sea cómoda y segura para su disfrute. DESCARGO DE RESPONSABILIDAD Gracias por comprar el XMAX STARRY 4. Para asegurar la mejor experiencia, por favor lea y comprenda el manual del usuario completamente antes del primer uso del XMAX STARRY 4. Recomendamos que conserve ese manual del usuario para futuras referencias. Esperamos que disfrute de la excelente calidad y rendimiento de su XMAX STARRY 4. El usuario debe ser mayor de edad en cualquier jurisdicción para comprar el XMAX STARRY 4, utilice este produc-	to con moderación. Este producto no debe ser utilizado por niños, mientras conduce u opera maquinaria pesada, menores de edad o mujeres embarazadas o en periodo de lactancia y por personas con enfermedades que amenazan la vida sin consultar primero al médico. Tenga en cuenta que el XMAX STARRY 4 no es un dispositivo médico y no está diseñado para administrar medicinas ni sustancias ilegales de ningún tipo, diagnosticar, curar, tratar, o prevenir enfermedades o cualquier otra condición. Cualquier uso ilegal de este dispositivo podría someter al usuario a severas multas, penas y/o encarcelamiento de conformidad con las leyes de su (y/u otras) jurisdicción. ESTE PRODUCTO NO CONTIENE NINGÚN MATERIAL BOTÁNICO. 3
VISTA GENERAL DEL XMAX STARRY 4  4	CONTENIDO DEL XMAX STARRY 4  5
GUÍA DE FUNCIONAMIENTO 1. CARGA  Cargue completamente el dispositivo al menos 6 horas antes del primer uso. Por favor utilice el cable USB-C suministrado para cargar su dispositivo. Un icono de carga aparecerá en la pantalla para indicar que se está cargando. Cuando el dispositivo está completamente cargado, el icono de carga siempre permanecerá encendido.  Cargue la batería con un cargador dedicado y de buena calidad. Por favor asegúrese de que la salida de la toma de pared no sea superior a 5V/1A, o dañará el dispositivo. 6	2. RECARGA Cómo usar el horno: Retire la tapa magnética de la boquilla y elija la sustancia botánica de su preferencia. Debido a la delicada tecnología del horno, por favor sea cuidadoso al embalar el horno y/o insertar la taza del horno y/o durante la limpieza.  Flores botánicas: Empaque la sustancia suelta en la cámara del horno, no permita que la sustancia supere la parte superior de la cámara del horno. Cápsula de dosificación: Abra la tapa de la cápsula dosificadora, cargue la sustancia en la cápsula de dosificación, luego inserte la cápsula de dosificación en la cámara del horno.   No sobre cargue la taza de la cámara. Se recomienda llenar la mitad de la capacidad de la taza. 7
3. ENCENDIDO/APAGADO  Presione el botón de encendido 3 veces, el XMAX STARRY 4 se encenderá y comenzará a calentarse en la configuración por defecto o en la última temperatura ajustada. Haga clic en el botón de encendido 3 veces para apagarlo y el XMAX STARRY 4 vibrará para indicar que se ha apagado. 4. DISFRUTE EL XMAX STARRY 4 Mientras se calienta, el " " seguirá parpadeando durante la etapa de calentamiento, el " " se volverá sólido y la vibración del dispositivo indica que está listo y se inicia la cuenta atrás del temporizador. Inhale a través de la boquilla y disfrute. Este dispositivo empezará a vaporizar automáticamente  8	5. AJUSTES DE TEMPERATURA  Pulse o mantenga presionado el botón de aumento de temperatura, presione o mantenga presionado el botón de disminución de la temperatura. Haga clic para cambiar por grado, mantenga para cambiar rápidamente. 6.CAMBIO DEL TEMPORIZADOR  XMAX STARRY 4 tiene 3 temporizadores, 4 minutos, 6 minutos y 10 minutos. Para cambiar entre 4 minutos, 6 minutos y 10 minutos, presione el botón de encendido y el botón de aumento simultáneamente por 2 segundos. 9
7. VISUALIZACIÓN EN GRADOS FAHRENHEIT Y CELSIUS Para cambiar a Fahrenheit, simplemente mantenga presionado el botón de encendido y el botón de disminución simultáneamente por 2 segundos.  8. AJUSTE DEL FLUJO DE AIRE Presione el botón de ajuste del aire hacia arriba o hacia abajo para ajustar la suavidad del flujo de aire.  10	9. VOLTEAR LA PANTALLA Mantenga el botón hacia arriba y hacia abajo simultáneamente por 2 segundos.  10. PANTALLA OLED  Nivel de batería Temperatura objetivo Temperatura actual 464°F 65:59 Temporizador de la sesión 11
11. LIMPIEZA Y MANTENIMIENTO Para mantener el XMAX STARRY 4 funcionando de manera óptima y conservar el sabor más puro, recomendamos que todas las partes que entran en contacto con el material o vapor sean limpiadas regularmente. Todas las partes removibles pueden desmontarse para una óptima limpieza. Boquilla y filtro Utilice un bastoncillo de algodón y limpie la parte interior de la boquilla, luego limpie nuevamente con una toalla de papel húmeda. Prepare el contenedor de vidrio lleno con alcohol isopropílico. Retire el relleno de la tapa magnética, y colóquela en el alcohol isopropílico.  12	Limpieza del horno de cerámica: utilice el cepillo para limpiar el interior y un bastoncillo de algodón sumergido en alcohol isopropílico.  * Consejo: Realice un ciclo de quemado a temperatura máxima por 2 minutos después de limpiar. Después de utilizar el XMAX STARRY 4 o cargarlo, por favor deje que el dispositivo se enfríe antes de almacenarlo. Se debe almacenar en un lugar limpio, seco y protegido contra los efectos del clima y fuera del alcance de los niños y mascotas. Si tiene alguna preocupación o problema, por favor apague el XMAX STARRY 4 y/o desconecte del cargador inmediatamente. No intente reparar ningún defecto usted mismo. 13
Contacte a nuestro servicio de atención al cliente directamente a support@topgreencig.com. NOTA:  NO TOQUE EL ELEMENTO CALFACTOR INMEDIATAMENTE DESPUÉS DE SU USO. NO LIMPIE TODO EL DISPOSITIVO CON AGUA O SUMERGIR. NO INYECTE NINGÚN LÍQUIDO O ACEITE EN EL HORNO DE ACERO INOXIDABLE. ASEGÚRESE DE DESACTIVAR EL DISPOSITIVO BLOQUEANDO. ASEGÚRESE DE QUE NO SE HA UTILIZADO DURANTE AL MENOS 30 MINUTOS Y QUE ESTÁ COMPLETAMENTE FRÍO. ADVERTENCIA: COMPONENTES CALIENTES. 14	SEGURIDAD Antes de su primer uso, lea y comprenda completamente las instrucciones, incluida la información de seguridad. Recomendamos que guarde estas instrucciones para futuras consultas. El incumplimiento de las advertencias puede resultar en un peligro para la seguridad que incluye descargas eléctricas, incendios, daños a la propiedad, lesiones corporales o la muerte. EDAD Debe ser mayor de edad en su jurisdicción para comprar o usar XMAX STARRY 4. Solo para uso de adultos. USO Nunca use el producto antes de revisar el manual en su totalidad. Si alguna sección o tema no está claro antes de su uso, comuníquese con el servicio de atención al cliente para obtener una aclaración. Este producto no debe ser utilizado 15
por niños, mujeres embarazadas o en periodo de lactancia, o personas con enfermedades potencialmente mortales sin antes consultar a un médico. Se recomienda que todos los usuarios consulten a un médico antes de usar con la hierba o concentrado elegido. Tenga en cuenta que XMAX STARRY 4 no es un dispositivo médico y no está destinado a diagnosticar, curar, tratar o prevenir ninguna enfermedad u otra condición médica. XMAX STARRY 4 no está destinado a administrar sustancias medicinales o ilegales de ningún tipo. Cualquier uso ilegal de este dispositivo podría someter al usuario a severas multas, sanciones y / o encarcelamiento según las leyes de su jurisdicción local. DAÑO Interrumpa inmediatamente el uso del producto si la unidad vaporizadora está dañada de alguna manera, incluyendo pero no limitado a: abolladuras, sobrecalentamiento, flujo de aire inusualmente restrictivo y / o fallas eléctricas. No intente 16	reparar el producto desmontando piezas no reemplazables, excepto la boquilla, el filtro, la herramienta de embalaje y la batería extraíble. Comuníquese con el servicio de atención al cliente para obtener ayuda con cualquier unidad dañada. Todas las baterías pueden explotar o estallar en llamas si se usan incorrectamente o se tratan mal. No desarme, corte, manipule, corte, aplaste, cortocircuite, incinere o exponga al agua, fuego o temperaturas altas por encima de 60 ° C o 140 ° F. Es su responsabilidad comprender los peligros y los procedimientos adecuados para manipular todas las baterías. No desechar en contenedores de basura ni tirar basura en el medio ambiente. Recicle o elimine de acuerdo con las leyes de seguridad locales. (Se sugiere cubrir los terminales con cinta aislante adecuada antes de desecharlos). 17
ADVERTENCIA ESTE PRODUCTO NO ESTÁ DESTINADO PARA NICOTINA. EL PRODUCTO ESTÁ DISEÑADO PARA USO LEGAL DE BOTÁNICOS Y CONCENTRADO ÚNICAMENTE. EL PRODUCTO NO CONTIENE NINGÚN BOTÁNICO O MATERIAL CONCENTRADO. MANTENGA EL DISPOSITIVO ALEJADO DE NIÑOS Y MASCOTAS. GARANTÍA LIMITADA El período de garantía del producto es de 12 meses a partir de la fecha de compra (con recibo) o de 12 meses a partir de la fecha de producción (sin recibo) para evitar defectos de fabricación, mano de obra y materiales. Este dispositivo está diseñado para el uso de concentrados y hierbas legales únicamente. Cualquier uso de XMAX STARRY 4 con sustancias ilegales anulará la garantía. Esta garantía cubre solo la base electrónica. Esta garantía no cubre la boquilla, la celda de la batería, la 18	herramienta de raspado ni otras piezas desmontables. La garantía no se aplica a daños causados por accidente, abuso, mal uso, desastre natural, error del usuario o uso fuera del uso previsto descrito en el manual. El uso fuera del uso previsto como se describe en este manual también incluye cualquier manipulación del dispositivo de cualquier manera, incluyendo pero no limitado a la modificación o la modificación para alterar la apariencia. La garantía tampoco se aplica a daños cosméticos, incluidos, entre otros, abolladuras, rayones / astillas en el acabado y / o piezas de plástico rotas. El desgaste normal del producto no está cubierto por la garantía. La degradación del rendimiento normal de las baterías tampoco está cubierta por la garantía. 19
Para realizar un reclamo de garantía, comuníquese con el servicio de atención al cliente en support@topgreencig.com. La factura de venta original, el código de autenticidad, las imágenes o videos y cualquier número de serie son necesarios para canjear la garantía. A discreción del fabricante, el servicio de garantía se proporcionará mediante la reparación del producto o el cambio del producto y / o pieza por uno nuevo o funcionalmente equivalente. ATENCIÓN AL CLIENTE Para cualquier pregunta o inquietud con el producto, su uso o defectos, comuníquese con el servicio de atención al cliente en support@topgreencig.com. Haremos todo lo posible para brindar una respuesta dentro de los dos (2) días hábiles posteriores a la recepción de la notificación por escrito. 20	

